



## Hanging Instructions

Photowall in budget quality

### Preparatory Work

The surface must be clean and dry. If the surface is porous, a plastered wall or chipboard for example, then it must be primed and any holes must be filled.

**NB! Only Use these instructions for the paste and not any other enclosed instructions.**

Use only the accompanying paste as it has been specially made for this wallpaper. Using other paste may cause bubbles or problems getting the wallpaper to adhere, etc.

### Mixing the Paste

Pour the powder slowly into 2.8 litres of cold water while mixing well.

Mix again after about 3 minutes.

Wait a further 15 – 20 minutes. Mix again before hanging.

### Hanging

Place the wallpaper on the floor before hanging to check that no panels are missing, damaged or faulty.

You will need the following tools: a roller or a paintbrush, a rag, a wallpaper brush and possibly a piece of string with a plumb bob to ensure that the first panel is straight.

Apply paste evenly to the wallpaper (there is enough paste for 20 – 24 m<sup>2</sup> so you do not need to use it sparingly), paying particular attention to the edges. Do not fold the panels or leave them to absorb the paste. Hang the panels as soon as the paste has been applied.

Hang the panel on the wall as per the instructions. Brush out any bubbles, starting from the centre and out towards the edges. Try to remove as many bubbles as possible. Small bubbles and creases will disappear as the wallpaper dries and stretches. Remove any spots of paste from the front of the wallpaper with a rag. When all the panels have been hung, remove any excess paste. Wait 24 hours to see the finished result.

Finished!

Sit back and enjoy your new view!